




## Basic Menu Map:



Home Screen

Press 




## Navigation

Press  from any screen to open the **Menu**.

Press  and  to scroll through the menu items.

Press  on the desired menu item to open.

The scroll bar appears on menus to indicate when additional text is available.

Press  to scroll down to view additional items.

Press  to scroll back up.

Press  to go to previous screen. Hold  to return to the **Home** screen.

